

- Supported versions
 - fw 2.616
 - fw 21.3.2017 3.202
 - fw 21.8.2017 3.210
- Requires Dahua driver
 - Download via TecomC4

Reminder: There may be additional costs from the third party for this functionality! Please check with the manufacturer or supplier.

Connecting TecomC4 to Dahua



1. Configure Dahua recorder and cameras
2. Create Bus Controller
3. Configure the following:
 1. IP Address
 2. Port
 3. Account (user name – default 'admin')
 4. Password (default 'admin')
 5. Enabled (tick to set to yes)
 6. Time Zone
4. Create Cameras
 1. Each camera is configured with an Address
5. Start communication with Dahua bus controller